Installation Manual for industrial application



- 1. Clean the outside of the pipe roughly with a cloth.
- 2. Wrap 5-6 layers of houshold foil or other foil around the pipe. No aluminium foil.
- 3. Wrap enough insulating tape around the foil to ensure that the Merus ring is firmly in place.
 - It must be possible to close the half rings completely again.
 - ! There should be no gap at the cut edges.
- 4. Install the Merus ring according to our standard installation instructions.
- 5. Wrap 5-6 layers of transparent foil or other foil around the Merus Ring. No aluminium foil.
- 6. Fix the outer foil with adhesive or insulting tape, so that the Merus ring is protected from splashing water from the outside.
- 7. Put some insulating tape on the right and left side of the Merus ring. This holds the Merus ring in position and everything is sealed.













- ! Please make sure that the Merus ring is wrapped quite well that no condensation water can be formed under the foil.
- In case of strong solar radiation, apply a UV-resistant protection around the complete installation.



<50V/m



Avoid strong magnetic field



Do not use in water



Avoid water splashes



5°C-95°C